

Wheel Replacement Instructions

- Take the door down and put it on the floor or table. If there is track molding installed, you will have to remove one side of it.
- Slip the wheel clip over the panel. Make sure the wheel clip lines up with the hole left from the broken wheel rivet. (*You should be able to feel the new rivet base slightly catch the old rivet hole*)
- Drill two pilot holes through the door panel and both sides of the wheel clip.
- Pop rivet the wheel clip in place.
- The door is now ready to be installed.

Note: During removal and installation of the track and any molding, inspect the track for foreign objects or improper alignment. Also make sure all of the track mounting screws have been completely seated.



Wheel clip



Installed wheel clip