

WALL SCREEN ACCESSORIES

Laser Pointers

The ultimate in presentation convenience. Select from three models.
 Laser Pointer
 Blinking Laser Pointer
 Jumbo Laser Pointer



Pull Rod

Reach pull bail on screens mounted out of reach with this handy accessory. 38" long.



Tilt Lock

Eliminates keystone when screen is tied back to removable hook which is magnetically attached to metal mounting plate with adhesive back.



T-Bar Scissor Clips

Use for attaching screens easily and without tools to dropped ceiling type "T" rails. Available in black or white.




Mounting Brackets

Use for convenient mounting to extend screen from wall to avoid obstacles such as chalkboards.

Model No. 6 extends screen from wall 6". Non-adjustable.



Model No. 11 extends screen from wall 10" or 14". Non-adjustable.



Model No. 23 adjusts for 14-1/2"-24".

